

POCKET GUIDE

**FROM VERSION
Q22 ONWARDS**

BT MINI


PREMIUM ESSENTIAL INTERCOM

 **ENGLISH**




 **MIDLAND®**

KEY DESCRIPTION



SWITCH ON



3" Press for 3 seconds




Flashes



Power on

SWITCH OFF



3" Press for 3 seconds




Flashes




Power off

VOLUME ADJUSTMENT

STATUS: WHILE LISTENING TO AN AUDIO SOURCE (INTERCOM, MUSIC, PHONE CALL)




Keep pressed to increase the volume



Keep pressed to decrease the volume

CHANGE LANGUAGE

STATUS: UNIT ON



+12"

Keep pressed for more than 12 seconds



"Battery status" in the various languages. **Release the button** as soon as you hear the announcement in the desired language


Frequency (GHz) 2.402 - 2.480

Max power 100(mW)

PAIRINGS

Pairing to:
Phone, TFT, GPS (Mono/Stereo)

Pairing to:
**Midland Intercom
Other brand Intercom**




Pairing to:
**Midland Intercom
Other brand
Intercom**

Pairing to:
**Midland Intercom
Other brand
Intercom**

Note: you can pair in total up to 3 intercom devices (Midland and/or other brands). The pairing on one button overwrites the previous one.

PHONE, TFT, GPS PAIRING

Status: **UNIT OFF**



7" Press for 7 seconds

Pairing phone

Flashes

Select BT Mini on phone, GPS or TFT

Pairing successful


MIDLAND INTERCOM PAIRING

Status: **UNIT ON**

1st



2nd



7" Press for 7 seconds **7"** Press for 7 seconds

Flashes

Flashes

Pairing intercom Pairing intercom

PAIRING SUCCESSFUL

Note: By following the same procedure, it is possible to pair two further devices to the **Up** or **Down** buttons.

OBI INTERCOM PAIRING

Status: **UNIT ON**



OBi

OBI intercom (Cardo...)

7" Press for 7 seconds

Flashes

Follow the intercom **pairing procedure** (see device instructions)


Pairing intercom

PAIRING SUCCESSFUL

Note: By following the same procedure, it is possible to pair two further devices to the **Control** or **Down** buttons.

OTHER BRAND INTERCOM PAIRING (UNIVERSAL INTERCOM)

STATUS: UNIT ON



7" Press for 7 seconds



Flashes

Use the phone
pairing procedure

Beep pairing intercom

PAIRING SUCCESSFUL

Note: By following the same procedure, it is possible to pair two further devices to the **Up** or **Control** buttons.

RESET BLUETOOTH PAIRINGS

STATUS: UNIT ON



3" Press together
for 3 seconds



Confirmation
(3 sec.)

EXIT THE PAIRING



RED AND BLUE FLASHING



x2 Press twice




change the flashing

INTERCOM

TO OPEN/CLOSE INTERCOM AND OBI MANUALLY

STATUS: UNIT ON AND PAIRED TO A PHONE



Press once



Beep




Flashes

Note: to open intercom, OBI and Universal intercom click on the button corresponding to the pairing carried out.

TO OPEN/CLOSE UNIVERSAL INTERCOM

STATUS: UNIT ON AND PAIRED TO A PHONE



Press once



Beep



Flashes

Note: to open/close the audio with a different brand device, use the voice call command (for some models, it is required to send the voice call twice).

Note: to open intercom, OBI and Universal intercom click on the button corresponding to the pairing carried out.

PHONE

TO MAKE A CALL

STATUS: UNIT ON AND PAIRED TO A PHONE



Press twice



Voice Assistance response (Google assistant, Siri)



Give instructions




Flashes




Call

TO ANSWER/END A CALL



Press once to answer/end a call


REJECT A CALL



Press for 3 seconds

TO ENABLE THE AUTOMATIC RESPONSE

STATUS: UNIT ON



Press 3 seconds




Enable



Flashes

TO DISABLE THE AUTOMATIC RESPONSE

STATUS: UNIT ON



Press 3 seconds



Disable



Flashes

Note: If Auto-Response is activated, it will automatically respond after 8 seconds.


MUSIC

PLAY/PAUSE

STATUS: UNIT ON AND PAIRED TO A PHONE




Select Music App




2"

Keep pressed for
2 seconds
Play/Pause



x2

Press twice
Next track



x2

Press twice
Previous track


MUSIC SHARE WITH PASSENGER

STATUS: UNIT ON AND PAIRED TO A PHONE



Select Music App

OPEN INTERCOM



2"

Keep pressed for
2 seconds



Music Share

Note: to stop the music share press the same button.

Note: you can only share music with a BTMINI version Q22 and following ones.



Scan the QR code to access the support page, update the software and find all info about BT Mini, including video tutorial and installation.

Midland World



To listen to the web radio download Midland
Connect from App Store or Google Play

