

## Midland Bike Guardian Wi-Fi Firmware update

### IT

1. Formatta la scheda che utilizzerai in un PC Windows (capacità massima della memory da usare per l'aggiornamento 32 GB)
2. Scaricare il nuovo Firmware nella sezione scarica al link :  
<https://www.midlandeuropa.com/it/p/bike-guardian-wi-fi-videocamera-dvr-da-moto-fhd-c1424.html>
3. Copiare il file FW55WIFI.bin nella directory principale della scheda TF
4. Inserire la scheda nella cam
5. Collegare la cam ad una fonte di alimentazione (non al PC)
6. La cam si aggiorna automaticamente
7. Dopo l'aggiornamento, il prodotto si accenderà automaticamente
8. Al termine dell'aggiornamento, il led rosso lampeggia: Registrazione
9. Inserire di nuovo la cam nel PC e cancellare il file del firmware

### EN

1. Format the card you will use using a Windows PC (for update use a max 32GB memory card)
2. Download new firmware in download section from : <https://www.midlandeuropa.com/en/p/bike-guardian-wifi-always-connected.html>
3. Copy the file FW55WIFI.bin to the TF card root directory
4. Insert the card into the cam
5. Connect the product with power supply (not to a PC)
6. The machine is automatically upgraded
7. After updating, the product will turn on automatically
8. When update is finish red led flashes: Record
9. Re insert memory inside PC and delete firmware file