

# HOW TO CHANGE LCD COLORS

## 5.3 Change LCD Light

5.3.1 Long press the【F】button on the panel to enter Menu mode, the “PH H” icon will show on the LCD display, short press the UP button to scroll through the menu functions.

5.3.2 With icon “FC X” shows on the display (FC stands for the Light function, 1 represents Light mode), Short press【F】button to change the Light color. Then long press the【F】button for 3s to confirm your selection.

## 5.4 Select the Color of the button LCD.

5.4.1 Long press the【F】button to enter Menu mode, the “PH H” icon will show on the LCD display, short press the UP button to scroll through the menu functions.

5.4.2 With “FL ON” shows on the LCD display (FL represents the button light, ON means light on, OFF means light off), short press the【F】button to turn on/off the button light. Then long press the【F】button for 3s to confirm your selection.