



Bluetooth 5.0

ULTRACOM


di  MIDLAND



2 - POCKET GUIDE


ON/OFF

CONTROLS DESCRIPTION



SWITCH ON

Status: device off



Press together 3 sec.




Jingle



Steady (1 sec)

SWITCH OFF

Status: device on



Press together 3 sec.




Jingle



Steady (3 sec)

VOLUME ADJUSTMENT


Status: device on, during the listening of the desired source.



Keep pressed to increase the volume



Beep



Keep pressed to decrease the volume




Beep

Note: The volumes of music, phone calls, and intercom are independent, and each of them can be adjusted while listening.

PAIRINGS


CONTROLS DESCRIPTION




Note: the audio source paired to CONTROL button (Music or navigator's indications) remains in background to the intercom communication opened between two people.

PHONE, GPS, TFT

Status: device off



Press 7 sec.



Pairing main phone



Flashes



Select "ULTRACOM by Midland" in your phone, GPS or TFT



Connected




Steady (3 sec)

RESET BLUETOOTH PAIRINGS AND DEVICE

Status: device on



Press together 9 sec.



Beep



Steady (1 sec)

Note: To pair a 2nd device, press one more time the CONTROL button during the pairing procedure.

MIDLAND INTERCOM

Status: device on



Press 7 sec.
(You can press any key)



Pairing intercom



Flashes



Beep



Steady (3 sec)

MIDLAND



Press 7 sec.
(You can press any key)



Pairing intercom



Flashes



Beep



Steady (3 sec)

MIDLAND INTERCOM

Status: device on



Press 7 sec.
(You can press any key)



Pairing intercom



Flashes



Beep



Steady (3 sec)

OBI



Follow the intercom pairing procedure
(see intercom's instructions)

UNIVERSAL INTERCOM



Follow the phone pairing procedure
(see intercom's instructions)

Attention: you can pair a maximum of 3 intercom devices (Midland, OBI or other brand), one for each button. A new pairing on the same button overwrites the previous one.

INTERCOM FUNCTIONALITY

The “Intercom” communication allows you to talk to one person at a time, through any of the paired intercoms, or to talk to more than one intercom device at the same time (Conference mode).



Intercom communication one person at a time

When the intercom communication is already open to one person, first close it and only then open the intercom communication to another person.



Conference mode

When the intercom communication already open to one person, just open the intercom to a second person without closing the first conversation. In Conference mode you can talk up to 4 people in a chain (Conference to 4). Each intercom device can have two communications open simultaneously.

Note: in the device with the Conference mode activated (intercom open to other two devices), you can however receive a phone call from the device paired to CONTROL (the music in background and the second device will be temporarily disconnected and will be connected again when the second intercom is closed).


Note: to talk with Rider 1 or Rider 3 repeat the procedure but press the buttons corresponding to the pairings.

Note: To enable/disable VOX (voice-activated intercom communication), enable/disable Noise Gate (microphone mute in the absence of voice), and enable/disable AGC (automatic volume adjustment based on speed), use the Midland Connect App.

FUNCTIONS DESCRIPTION

Front button – Rider 1:
(Midland/OBI/Universal Intercom)


Back button – Rider 3
(Midland/OBI/Universal Intercom)



Control button – Rider 2
(Midland/OBI/Universal Intercom) – Vox

Intercom functions are accessed by pressing once the buttons corresponding to the pairings.

OPEN/CLOSE INTERCOM AND OBI MANUALLY



Press once the button corresponding to the pairing

Beep


Flashes

OPEN INTERCOM BY VOICE (VOX)

	Say “Hello”
	VOX
	Flashes
	Silent for 1 minute; intercom closes
	Beep

Note: the voice activation is possible only with the intercom paired to the **Control button–Rider 2** (VOX must be active).

TO OPEN/CLOSE UNIVERSAL INTERCOM



Press once the button corresponding to the pairing

Beep


Flashes

Note: to open/close the audio from the different brand device, use the voice call comand (for some models it is necessary to send the voice call twice).


PHONE FUNCTIONALITY

FUNCTIONS DESCRIPTION

Play/Pause and Voice assistant



TO ACTIVATE VOICE ASSISTANT (NO AUDIO ACTIVE)



Press twice


Voice assistant response (Google assistant, Siri)

Give instructions

Call

Note: the voice assistant is available on the main device

ANSWERING/ENDING/REJECTING A CALL



Press once to answer/end a call



Press for 2 sec. to reject a call

Note: you can press any key.

MUSIC SHARE WITH PASSENGER

Select music App

Open Midland intercom (manually or by voice)



Press 2 sec

Music Share On

Note: it is possible to share music only with a Midland intercom same model

MUSIC


Select music App



Press 2 sec Play/Pause



Press twice Next track



Press twice Previous track

Frequency (GHz)	Max power (mW)
2.402 – 2.480	100



Scan the QR code to access the support page, update the firmware, download this pocket guide on your smartphone and find all info about Midland UCS PRO, including video tutorial and installation.



Download Midland Connect from App Store – Google Play



Distributed by:
OMNIA RETAIL srl
Via T.Grossi, 5 - 20841 Carate Brianza
MB (Italia) - www.omniaretail.com

Produced or imported by:
MIDLAND EUROPE srl
Via R. Sevardi 7 - 42124 Reggio Emilia
Italia