

PMR446 channel list

CH	frequency Mhz	CTCSS	CH	frequency Mhz	CTCSS
1	446.00625	selectable	17	446.00625	114.8
2	446.01875	selectable	18	446.01875	114.8
3	446.03125	selectable	19	446.03125	114.8
4	446.04375	selectable	20	446.04375	114.8
5	446.05625	selectable	21	446.05625	114.8
6	446.06875	selectable	22	446.06875	114.8
7	446.08125	selectable	23	446.08125	114.8
8	446.09375	selectable	24	446.09375	114.8
9	446.10625	selectable	25	446.10625	114.8
10	446.11875	selectable	26	446.11875	114.8
11	446.13125	selectable	27	446.13125	114.8
12	446.14375	selectable	28	446.14375	114.8
13	446.15625	selectable	29	446.15625	114.8
14	446.16875	selectable	30	446.16875	114.8
15	446.18125	selectable	31	446.18125	114.8
16	446.19375	selectable	32	446.19375	114.8

LPD channel list

CH	frequency Mhz	CH	frequency Mhz	CH	frequency Mhz
1	433.075	24	433.650	47	434.225
2	433.100	25	433.675	48	434.250
3	433.125	26	433.700	49	434.275
4	433.150	27	433.725	50	434.300
5	433.175	28	433.750	51	434.325
6	433.200	29	433.775	52	434.350
7	433.225	30	433.800	53	434.375
8	433.250	31	433.825	54	434.400
9	433.275	32	433.850	55	434.425
10	433.300	33	433.875	56	434.450
11	433.325	34	433.900	57	434.475
12	433.350	35	433.925	58	434.500
13	433.375	36	433.950	59	434.525
14	433.400	37	433.975	60	434.550
15	433.425	38	434.000	61	434.575
16	433.450	39	434.025	62	434.600
17	433.475	40	434.050	63	434.625
18	433.500	41	434.075	64	434.650
19	433.525	42	434.100	65	434.675
20	433.550	43	434.125	66	434.700
21	433.575	44	434.150	67	434.725
22	433.600	45	434.175	68	434.750
23	433.625	46	434.200	69	434.775

