

R1 MESH




HIGH DEFINITION SOUND BY 

 **MIDLAND**[®]

ON/OFF

KEY DESCRIPTION



SWITCH ON

Press for 3 seconds



Beep



Flashes

SWITCH OFF

Press together for 3 sec.




Notification jingle



Flashes

PAIRINGS

KEY DESCRIPTION



PHONE, GPS, TFT PAIRING

Press for 5 seconds



Beep



Flashes



Select R1 Mesh on
PHONE, GPS or TFT



Beep



Confirm (1 sec.)

Note: to pair a 2nd device in mono audio, repeat this procedure using Vol -.

PAIRINGS

MIDLAND/OBI INTERCOM PAIRING



OBi
OBI Intercom
(Midland, Cardo, Uclear)

Press for 7 seconds



Flashes



Confirm (1 sec.)

Follow procedure to pair with
intercom

Pairing successful

Note: to pair another OBI intercom, follow the same procedure using the Up button.

OTHER BRAND INTERCOM PAIRING



Press for 7 seconds



Flashes




Confirm (1 sec.)

Follow procedure to pair with
phone

Note: to pair a second intercom of another brand, follow the same procedure using the Down button.

Note: a maximum of 2 intercoms (Midland, OBI or other brand) can be paired, one on each button. A second pairing on the same button overwrites the previous one.

RESET BLUETOOTH PAIRINGS



Press together 5 seconds



Vocal announcement



Steady



Press together 3 seconds




Beep



Confirm (1 sec.)

FACTORY RESET




Press together 5 seconds



Vocal announcement



Steady



Press together 3 seconds




Beep





Confirm (1 sec.)

INTERCOM FEATURES


MESH IDENTIFICATION CODE (ID) SELECTION





Press together, 1 time

	Voice ID
	Flashes

5 sec. to choose the personal ID (press **Vol+** to increase and **Vol-** to decrease ID figure)




	Flashes
---	---------

 Confirm ID and group

PLEASE NOTE: TO COMMUNICATE VIA MESH, PARTICIPANTS MUST HAVE DIFFERENT IDS AND ACTIVE MESH.

FUNCTION DESCRIPTION




ON/OFF Mesh


Rider 2 (Midland/OBI/Universal Intercom)

Rider 1 (Midland/OBI/Universal Intercom)


NOTE:

All Intercom features are accessible with 2 clicks 

TO OPEN/CLOSE MESH COMMUNICATION



Press 2 times

	Jingle
---	--------

Flashes the colour of the group selected (see **TABLE 1**)

R1 Mesh uses only the Dynamic repeat mode.



ID 1



ID 2



ID 3




ID 4...

Guests can only listen.

Group Mesh Dynamic Repeat: 6 people.

Group Mesh Dynamic Repeat Secure: 6 people with Secure key assigned for private communications available through the app.

TABLE 1 - IDS ASSIGNED TO THE VARIOUS GROUPS:

GROUP	ID	GUESTS	LED
 Mesh Dynamic Repeat	1-6	Infinite	
 Mesh Dynamic Repeat Secure	1-6	Infinite	

INTERCOM FEATURES

TO OPEN/CLOSE INTERCOM MANUALLY



Press 2 times



Beep



Flashes

Note: to communicate with Rider 2 repeat the process by pressing the **Up** button.

TO OPEN/CLOSE UNIVERSAL INTERCOM



Press 2 times to open or close
the Universal Intercom



Beep



Flashes

Note: to activate/deactivate the audio from a different brand device, use the voice call command (for some models it is necessary to send the voice call 2 times)


TO OPEN/CLOSE INTERCOM BY VOICE (VOX)



 Say "Hi"

 Jingle


 Flashes

 Silent for 1 minute. **the intercom deactivates**


 Beep

Note: Voice activation is only possible with an intercom paired with the **down** button (Vox must be active).

VOX ACTIVATION/DEACTIVATION



Press together for 3 seconds

 Voice announcement

INTERCOM FEATURES

NOISE GATE (INTELLIGENT MICROPHONE POWER OFF)



Press together for 3 seconds



Voice announcement

AGC ACTIVATION/DEACTIVATION (AUTOMATIC VOLUME ADJUSTMENT)



Press together for 3 seconds




Voice announcement

PHONE FEATURES

FUNCTION DESCRIPTION


Play/Pause



Voice Assistant
(Phone on Vol+)

Voice Assistant
(Phone on Vol-)

NOTE:

All **Phone** features are accessible with 1 click 

VOICE ASSISTANT

Press 1 time



Voice Assistant Response
(Google assistant, Siri)



Give instructions



Call

Note: If you have a phone paired with the **Vol -** button, use the **Down button**.

PHONE FEATURES

ANSWERING/ENDING A CALL REJECTING A CALL



Press 1 time to answer/end a call



Press for 3 sec. to reject a call

Note: any button can be used.

MUSIC



Select Music app



Press 1 time Play/Pause



Press 1 time Next track



Press 1 time Previous track

MUSIC SHARE WITH PASSENGER



Select Music app

Activate Midland Intercom
(manually or using Vox)



Press 1 time



Voice announcement

Note: You can only share music with a Midland Intercom.

Frequency (GHz)	Max power (mW)
2.402 - 2.480	100

For more info visit: <https://support.midlandeuropa.com/>

Select a product and:

Watch **tutorial video** - Download **software**

Midland World



Download Midland Connect from App Store or Google Play

