

**PMR446 channel list**

CH	frequency Mhz
1	446.00625
2	446.01875
3	446.03125
4	446.04375
5	446.05625
6	446.06875
7	446.08125
8	446.09375
9	446.10625
10	446.11875
11	446.13125
12	446.14375
13	446.15625
14	446.16875
15	446.18125
16	446.19375